



HASAR 9000 (ALT Mode)




Start of Configuration

KL00



International Keyboard
(ALT Method)



End of
Configuration