

# Honeywell 1200g (ALT MODE)



Configuración predeterminada estándar de los productos

**ALT MODE**



KBDALT7.


**4 Characters**

# HASAR 9000 (ALT Mode)




Start of Configuration

KL00




International Keyboard  
(ALT Method)



End of  
Configuration


## HASAR 9000 (Todo Minuscula)



Start of Configuration



Alphabet always Lower case



End of  
Configuration

# Voyager 1200G (Configurar prefijo F8)



PRECA2.

**Clear All Prefixes**

Borrar prefijos



PREBK2.

**Add Prefix**

Agregar prefijo



K9K

**9**

9



K9K

9

9



K9K

9

9



K7K

7

7



MNUSAV.

**Save**

GUARDAR